Bipedinno 12-DOF Waist-high Robot

Instruction Manual

Version 1.18



Trademark

Innovati[®], $\stackrel{\bullet}{\blacktriangleright}$, and BASIC Commander[®], are registered trademarks of Innovati Inc. InnoBASIC[™] and cmdBUS[™] are trademarks of Innovati Inc.

Copyright ©2008-2009 by Innovati Inc. All rights reserved.

In view of unceasing improvement of products, this document and the product mentioned in this document are subject to be changed by the company without notice. It is forbidden to reproduce and distribute any part or all of the contents of the product without the written approval or authorization by the company.

Disclaimer

The user shall undertake all the risks in the applications where this product is used. The company shall not be liable for any direct, indirect or consequential damages due to the use of the product including but not limited to the loss of equipment, the loss of human safety and health and the loss of profit and reputation. The product of the company shall not be used in life saving or any related instrument and equipment. Children under 14 shall not use this product for any related experiment without being accompanied by adults.

Errata

We hope the users may regard this document as a lively and practical instruction manual. We have put tremendous efforts in making this instruction manual complete and correct; however, there may be unavoidable missing parts or errors. With a view to providing the user updated and complete information in the instruction manual, we keep improving and supplement the contents of this instruction manual. If you find any error in this manual, please contact us via the e-mail service@innovati.com.tw. Any related update information will be disclosed on our website. Please visit our website http://www.innovati.com.tw for more updated information.

Precautions

- This kit comprises 2 modules, BASIC Commander[®] and Servo Runner A, each with respective instructions for use and functions. Please refer to these for optimal effects.
- When installing BASIC Commander® to the Command Board, make sure the input voltage is within the 6-12V range, otherwise the module may burn.
- The input voltage to the Servo Runner A must correspond to the voltage rating of the servo. **Servos provided in this kit are rated 4.8-6V**; over or under voltage may cause unpredictable results, even burning of the motor. Make absolutely sure of the correct voltage before connecting the power supply.
- The kit provides a total of 12 servos. When operated simultaneously, they consume a large current; make sure the power supply or battery connecting to Servo Runner A is capable of providing **8A of current**, so as to properly operate the kit. Insufficient current may cause unexpected results and damage of the kit.
- When using a battery power supply to the module, the voltage may lower after some while of operation and cause abnormal actions of the kit. In such case, remove and fully charge the battery before using again. If prolonged testing and operation is required, we suggest you use a power supply unit to ensure uniform performance.

Prior to assembling the kit, install $InnoBASIC^{TM}$ Workshop as per the content of the CD; also make sure that the PC communicates with BASIC Commander[®] via a USB cable connection, so that the entire assembly can be accomplished.

Table of Contents

Part List	1
Tools	4
Assembly Procedure	5
Calibration Servos	5
Assemble the Leg Frames	10
Connecting Top Board with Module	16
Fine-Tuning Initial value of Servo	21
Structure fine-tuning	21
Software fine-tuning	21
Dayfarm Damanatrativa Matiana	27

Part List

Item	Illustration	Qt'y	Specifications and instructions
	Assembly Kit l	Parts	
Main Board for installing module		1	PC installation board for linking robot electronic modules with its leg parts; provides versatile layout of module or power supply accessories.
Top Board for installing module		1	PC board for installing electronic module of the robot and connecting with the main board; provides versatile layout of modules.
Aluminum Foot Bracket		2	For connecting with the Ankel Servo Bracket.
Aluminum Servo Bracket		12	For accommodating and fixing servo; lock holes are provided for connecting with another Servo Bracket or U-shape Bracket.
Aluminum U-shape Bracket, 27mm		4	Provides connection with the Servo Bracket and movement space of the Servo; it also provides connection with two U-shape Brackets for different applications.
Aluminum U-shape Bracket, 22mm		8	Provides connection with the Servo Bracket and movement space of the Servo; it also provides connection with two U-shape Brackets for different applications.

1

Servo		12	Servo provides for 180° rotation moves capable of simulating articulation behaviors; connections with signal, power and ground are required for the operation. Pay attention to wire polarity. Avoid having the servo sustained to a same movement for a long period of time, to prevent wearing the motor. Dimensions (LxWxH): 40.6mmx20.0mmx42.8mm Weight: 73 g, Speed: 0.33 sec/60° Torque: 7.4 kg/cm
Screw A		48	ISOT 3 x 8 mm
Screw B	The same of the sa	10	ISOP 3 x 6 mm
Screw C	The state of the s	20	ISOP 3 x 10 mm
Screw D		32	ISOP 2 x 5 mm
Screw E	TO STATE OF THE PARTY OF THE PA	40	TP1P 2 x 6 mm
Screw F		8	TP1P 2 x 8 mm
Screw G	No. Orange	4	ISOF 3 x 6 mm
Screw H		8	ISOF 2 x 5 mm
Nut A	8	90	3 x 5 mm
Nut B	•	32	2 x 4 mm
Washer A	0	72	3 x 0.4 x 8 mm
Washer B	O	12	3 x 1 x 6 mm
Bearing		12	3 x 4 x 8 x 9.5 mm

Hex post, copper		4	30 mm
	Module Kit	S	
BC1		1	Innovati [®] BASIC Commander [®] , capable of storing programs and controlling operations of modules
Servo Runner A	0	1	Innovati [®] Servo Runner A, for controlling individual servos.
Command Board		1	Used for installing BC1, with spare cmdBUS [™] allowing user to connect with Innovati [®] modules.
Servo Power Line		1	Cable for connecting Servo Runner A with Power Supply Unit.
Command Board Power Line		1	Cable for connecting Command Board with Servo Runner A's Power Supply.
$\mathrm{cmdBUS}^{^{\mathrm{TM}}}$		1	Signal cable for connecting Command Board with Servo Runner A.
Servo Extension Cable		4	Extends controlling signal cable of the Servo, so that the user may perform Servo control with a larger range or longer distance.

USB cable	1	Links BC1 with PC, allowing downloading of PC program to BC1, or performing communication in Debug Mode.
Cable Strap	12	Used for fixing wires, so that they do not tangle or affect motions unexpectedly during the operation of the Servo.

i. Tools


- Cross Screwdriver (2mm and 3 mm).
- Long Nose Pliers
- Screw Glue (selectively used between nut and Bracket joints, to prevent the nut from loosening.)

ii. Assembly Procedures

Calibrating Servos

Before starting installation, verify if the servo horn is at the correct position; if not, calibrate as follows:

◆ Connect servo, Servo Runner A, Command Board, and power supply cable in the sequence as illustrated below.




* When the Command Board or Education Board shares the power supply with Servo Runner A, please notice that the voltage of this kit should be 6V (please refer to Notices). It is recommended to use a voltage regulator to ensure that the voltage is within the safe range.

- i. Connect the PC and BASIC Commander® with a USB cable.
- ii. Make sure that the DIP switch on the Command Board is set at the 0 position (power off state). If it is not at the 0 position, please poke it to the 0 position.
- iii. Connect the power line of the servo to the power supply. (Please make sure that the voltage and current from the power supply are within the ranges required by the servo. After the power line is connected, the servo may make a transient motion due to receiving a switch surge; this is normal. While connecting the power line, please pay attention not to place your hands within the space where the servo may move to avoid being clamped.)


iv. Start the InnoBASIC[™] Workshop




v. Click the "Tools" item in the menu bar on the top.




vi. Click the "Motion Editor" in the pull-down menu (If a warning window appears, it means that the BASIC Commander[®] is not correctly connected. Please check if the USB cable is connected or unplug and then plug it again to ensure a correct connection. Exit the Motion Editor and then re-click this button.)




vii. If the connection is correct, the message "Downloading servo manager..." will be displayed on the PC screen meaning that the program is being downloaded. Please poke the DIP switch on the Command Board to the 1 position and wait a moment.




viii. After the downloading is complete, a notification window will appear. Please make sure that each servo has been connected correctly. After confirming all the connections, please click "OK". (If "Cancel" is clicked, the Motion Editor will be closed. If there is any component is incorrectly connected at this moment, please click "Cancel" to terminate the program.)



ix. Please pay attention not to place your hands within the space where the servos may move into to avoid being clamped. Please check the checkbox for activating the servos on the left side to move all the servos to their central points. Please note that the number next to it should be 1500. If it is not 1500, please click the number directly, enter the number 1500 and then click "Enter".




♦ Check if the disks of all servos are at correct position; in case of any deviation, remove the central screw and pull off the disk, adjust it to the correct angle and re-lock.




♦ While making the assembly, before fixing the disk, make sure the disk is maintained at the correct angle. In case the disk is moved, follow this procedure to adjust it, to prevent from any unexpected movement or damage of the parts.


↓ Installing the bearing (For reference only. Please do not assemble it first.)





Fixing the servo (For reference only. Please do not assemble it first.)




A. Assemble the leg frames












↓ Confirmation of the Right Leg Frame



Confirmation of the Left Leg Frame





iii. Connecting the Left and Right Legs




B. Connecting Top Board with Module

i. Assemble Top Board with Command Board







ii. Assemble Main Board with Servo Runner A




iii. Install servos and connect with Main Board




Place a servo in each top Servo Plate of the left and right leg frames. Turn the leg frames outward 90 degrees as shown for easy installation.




Fix servos to respective Servo Plates; insert Screw A with Washer A downwards, passing through servo and then Servo Plate and then fix the screw with a Nut A on the inside of Servo Plate.




Place Main Board on top of the just assembled servos, and lock with Screws F. Note that Screw F is of self-tapping. Use a lower torque if a powered screwdriver is used. Lock the two diagonal screws first, check the screw hole alignment and then lock another two screws.



Add Screw B to Top Board and lock with the copper post. Place Top Board on top of the 8 screw holes that fix the servos; from lower side of Main Board, secure Nut A with long nose pliers.






Connect Command Board and Servo Runner A with Command Board Power Line. Make sure red line is connected to + and black to -. Incorrect connection may damage the module.


Use correct Servo Power Line to connect with the Servo Board; select corresponding connector for the battery pack. Ensure correct polarity; incorrect connection may damage the module.

Connect cmdBUS $^{\text{m}}$ cable to Command Board and Servo Runner A. Maker the red line connects to "Vin". Incorrect connection may damage the module.

Install the rest 10 servos respectively into each Servo Plate and fix them with Screw A, Washer A and Nut A. Then lock U-shape Bracket onto servo with Screw E. While locking these screws, make sure the each U-shape Bracket is either parallel or perpendicular to the servo. DO NOT disturb the disk before fixing it.



Connect the control line of each servo to the corresponding pins on the Servo Module. Make sure that settings of servo numbers in the program conform to servo numbers on the Servo Module; only the following connection may ensure movements as programmed in the example.



** A Servo number is provided beside each Servo Module. Note that the white wire is signal, red the power and black the Ground. Connect them as indicated on the module, to avoid any damage of the module.

iii. Fine-tuning initial value of servo

There might be some positioning errors in each servo that are possibly caused by installation or mechanical errors. Therefore, before assembling and installing, it is necessary to perform a two-step adjustment so as to allow the follow-up operations to be positioned correctly.

A. Structure fine-tuning:

- Prior to the final step of installation, the disks of all servos are not yet fixed to the structure. You may unscrew the central black screw and adjust position of the disk now.
- Connect all servos to the Servo Module and connect to the power supply. Referring to servo calibration procedures, let all servos move to their center point respectively.
- Check if all screw holes align with holes on the disk. If not, unscrew the central screw and pull up the disk, align disk holes to holes on the structure and lower the disk.


*Both the PC and aluminum are flexible to a certain extent. In case hole positions on the PC board misalign with the hole positions of servos, just slightly pull PC board up and adjust the disk, by lifting it up, to a desired angle and replace it.

• Align holes of all 12 servos one by one, and then proceed with final fixing of the installation.

B. Software fine-tuning:


- After completing structure fine-tuning and fixing disks (the final step of installation), proceed with software fine-tune program.
- Enter fine-tune value of each servo respectively and adjust all motors to their desired positions. In case satisfactory result cannot be achieved within the limit range (127~-128), go back to structure fine-tune and readjust the structure.
- * Make sure all disk screws are tightened and all servos are within the tolerance range while performing software fine-tuning.

B_1. Connect the PC and the BASIC Commander® on the robot with the USB cable




The connectors at the two ends of the USB cable are of different sizes, so please connect the smaller one to the BASIC Commander.

B_2. Make sure the DIP switch on the Command Board is at the 0 position. If not, please poke it to the 0 position.




B_3. Connect the power line of the servo to the power supply (Please make sure that the voltage and current from the power supply are within the range required by the servo. After connecting the power line, the servo will make a transient motion due to receiving the switch surge, which is normal. While connecting the power cord, please pay attention not to place your hands within the space where the servo will move into to avoid being clamped.)




B 4. Start InnoBASIC[™] Workshop




B 5. Click "Tools" in the menu bar on the top




B_6. Click the "Motion Editor" in the pull-down menu (If a warning window appears, it means that the BASIC Commander[®] is not correctly connected. Please check if the USB cable is connected or unplug and then plug it again to ensure a correct connection. Exit the Motion Editor and then re-click this button.)




B_7. If the connection is correct, the message "Downloading servo manager..." will be displayed on the PC screen meaning that the program is being downloaded. Please poke the DIP switch on the Command Board to the 1 position and wait a moment.




B_8. After the downloading is complete, a notification window will appear. Please make sure that each servo has been connected correctly. After confirming all the connections, please click "OK". (If "Cancel" is clicked, the Motion Editor will be closed. If there is any component is incorrectly connected at this moment, please click "Cancel" to terminate the program.)




B_9. Please pay attention not to place your hands within the space where the servos may move into to avoid being clamped. Please check the checkbox for activating the servos on the left side to move all the servos to their central points. Please note that the number next to it should be 1500. If it is not 1500, please click the number directly, enter the number 1500 and then click "Enter".



B_10. Click the "Adjust Offset" button at the upper right corner.




B_11. If the fine tune values are not yet stored, the Filename will be "Untitled". The user can specify a preferred name while storing the file.




B_12. Observe the servo that requires the fine tune and click the corresponding arrow buttons. The servo will rotate in the selected direction. Please make


sure that the rotation is in the correct direction. If the reverse rotation is required, click the opposite arrow button. Adjust each servo to its central point one by one.




B_13. Please note the values after fine tune. Click "Save", select the location for storing the file, enter a preferred filename, and then click OK to save the values in the PC. If it is required to query or download the values, click "Load" to read out the values.



B_14. Click the "Close" button at the lower right corner to close the window.




B_15. After returning the "Edit Servo Motion" window, click the "Exit" button at the lower right corner to close the fine tune operation.




iv. Perform Demonstrative Motions


- 4_1. Please copy the folder "12-DOF Bipedinno Doc" to the PC.
- **4_2.** In the InnoBASIC $^{\text{\tiny TM}}$ Workshop, click "Tools" in the menu bar on the top.




4_3. Click "Motion Editor" in the pull-down menu.




4_4. Click the button "Match" at the bottom of the Motion Editor.




4_5. Click the "Browse" button at the lower left corner.




4_6. Set the "Browse for Folder" location to the "12-DOF Bipedinno frame" folder under the "12-DOF Bipedinno Docs" folder and then click the "OK" button.



4_7. Please click the "12-DOF Bipedinno frame0.frm" below the motion files on the left side, click the "Frame 0" under the "Module 0" and then click the ">>" button.




4_8. Make sure that the "Frame 0" below the Module 0 has become "12-DOF Bipedinno frame0.frm".




After the download is complete, the original text "Frame 0" will turn into "12-DOF Bipedinno frame0.frm".

4_9. Now click the "12-DOF Bipedinno frame 1" below the "Frame Files" and "Frame 1" below the "Module 0" as the two steps describe above. Repeat the operation for all the motions till Frames 0-11 have been downloaded to the corresponding frames.




4_10.After all the download operations are complete, it is clear that all the motions above "Motion 12" and below the "Module 0" have been changed to the


corresponding motions.




4_11.After the verifying the operations, click the "Close" button at the lower right corner to close the window for setting the corresponding motions.




4_12.In the Edit Servo Motions window, click the "Exit" button at the lower right corner to close the Motion Editor.




4_13.Click "File" in the menu bar and click "Open".







$4_14.Please$ select the "12-DOF Bipedinno Walk Demo" in the folder and click "Open".



4_15.Move to the 27th line of the program to see the Initial Function. (To move within the program, the user can also click the mouse button at any position in the program and then rotate the mouse wheel to scroll the program page.)





4_16.Update the fine tune values, which are recorded during the software fine tune, into the Initial Function to replace the original values of "0".



4_17.Poke the DIP switch from the 1 position to the 0 position to prevent the robot from starting the motion directly after the program is successfully created.

1





- **4_19.**Remove the USB cable that has been connected to the robot and place the robot at a location prepared for performing the motion operations.
- **4_20.**Poke the DIP switch from the 0 position to the 1 position. The robot will perform a forward movement according to the demonstrative program.